




Adult assembly
required



THIS INSTRUCTION BOOKLET CONTAINS IMPORTANT SAFETY INFORMATION.
PLEASE READ AND KEEP FOR FUTURE REFERENCE.

- **DO NOT RETURN THIS PRODUCT TO THE STORE.** Individual stores do not stock replacement parts. For immediate assistance with assembly or to report missing / damaged parts, please contact our customer service team. Toll-Free: **1-877-637-3590** | Email: **asprod2015@gmail.com**
- Please have your assembly instructions and parts list ready, and provide the Model Name and Part Description / Part ID.
- Replacement parts are shipped **FREE** of charge within 90 days of purchase (proof of purchase required).
- After 90 days, additional parts may be available for a nominal fee.

Stock Number:

BH2602125171002 (Walnut and Cream)

Lot Number: _____

Date Purchased: ____/____/____

Review your purchases, thank you!



Share your feedback to help other shoppers
Link for this product is as below:
www.walmart.com



Scan me !

For online
customer
service,
please scan
the QR Code
with your
smartphone.

**Manufactured By: Saigon Furniture Co.,Ltd.
Dong Nai, Vietnam.**
TEL: 1-877-637-3590 EMAIL: asprod2015@gmail.com



We are available to assist you Monday - Friday
from 9:00 am - 5:00 pm Eastern Standard Time.
1-877-637-3590

Page 1/8



Quality Guarantee

- Should this product be defective in workmanship or materials, or fail under normal use, we will provide replacement parts for up to one (1) year from the date of purchase.
- This furniture is designed to meet your highest expectations, and we guarantee your satisfaction.
- This warranty gives you specific legal rights; you may also have other rights which vary from State to State.
- This warranty applies only to customers who purchased the product from Walmart stores or Walmart.com and is valid only with proof of purchase.



General Information, Tips & Tricks

- **IMPORTANT:** Read all instructions carefully before starting.
- Please follow the steps in the correct order to avoid assembly difficulties or damage to parts.
- Failure to do so may result in improper assembly or product damage.
- **Check Parts:** Ensure all parts are included. Most boards are labeled with removable stickers for easy identification.
- **Prepare Workspace:** Work in a spacious area, preferably on a carpeted surface, near the final location of the unit.
- **Tightening:** Do not fully tighten bolts until all steps are completed. Ensure all bolts are securely fastened before use.
- Looking for online assembly instructions? Visit: <https://www.saigon-furniture.com/customer-care>



Safety and care

- Do not allow children to climb or play on the chair.
- Clean the product using a soft cloth and a high-quality furniture polish. Avoid using harsh chemicals or abrasive cleaners.
- Always move your furniture with care. Never push or drag the unit, as this may cause damage.

DO NOT USE POWER TOOLS TO ASSEMBLE THIS PRODUCT. POWER TOOLS MAY OVERTIGHTEN OR SPLIT THE PARTS, LEADING TO PRODUCT DAMAGE.




Help and support


- **DO NOT RETURN THIS PRODUCT TO THE STORE.** Individual stores do not stock replacement parts. For immediate assistance with assembly or to report missing/damaged parts, please contact our customer service team. Toll-Free: **1-877-637-3590** | Email: **asprod2015@gmail.com**
- Please have your assembly instructions and parts list ready, and provide the Model Name and Part Description / Part ID.
- Replacement parts are shipped **FREE** of charge within 90 days of purchase (proof of purchase required).
- After 90 days, additional parts may be available for a nominal fee.




Parts and Hardware List




A Chair Back x2



B Chair Seat x2




C Side Stretcher x4




D Front Stretcher x2



E Left Leg x2




F Right Leg x2




1 Ø1/4"x80mm Bolt x8




2 Lock Washer x20




3 Flat Washer x20




4 Ø1/4"x40mm Bolt x4



5 Ø1/4"x60mm Bolt x8




6 Ø4x45mm Screw x12



7 Allen Wrench x1

Tool required



Phillips head screwdriver (not provided)


Chair Assembly

1


Align and attach the Chair Seat (B) to the Chair Back (A) using Bolts (1), (4) and Washers (2), (3).
IMPORTANT: Hand-tighten bolts initially, then securely tighten using the provided Allen Wrench (7) once all parts are aligned.



WARNING: DO NOT USE POWER DRILLS OR DRIVERS TO INSERT BOLTS. EXCESSIVE FORCE MAY DAMAGE THE PRODUCT. USE ONLY THE ALLEN WRENCH PROVIDED.




1




Ø1/4"x80mm Bolt x4

2




Lock Washer x6

3



Flat Washer x6

4




Ø1/4"x40mm Bolt x2

Chair Assembly


2

Attach the Side Stretchers (C) to the Chair Back.



3


Attach the Front Stretcher (D) to the Left Leg (E) and Right Leg (F) as shown.




Chair Assembly

4

Attach the leg assembly (E), (F), (D) to the seat corners and Side Stretchers. Secure the legs to the seat using Bolts (5), Washers (2), (3). Tighten all Bolts with the Allen Wrench.



5




Ø1/4"x60mm Bolt x4

2



Lock Washer x4

3



Flat Washer x4


Chair Assembly

5


1. Place the assembled chair upside down on a table. Secure the stretchers to the legs and the chair back using Screws (6). Tighten them with a Phillips head screwdriver (not provided).
2. Carefully turn the chair to its upright position.

Repeat the procedure to assemble the remaining Chair.


5.1




5.2



Use the adjustable levelers to balance the chair.



6



Ø4x45mm Screw x6

Replacement Parts


STOCK #: ☐ BH2602125171002 (Walnut and Cream)

IF YOU NEED TO ORDER ANY PARTS, PLEASE USE THE LIST BELOW.

Please email photos of the defect and proof of purchase to: asprod2015@gmail.com

Parts will be shipped FREE of charge within 90 days of purchase with proof of purchase.

Replacement parts and services are only available for purchases made from Walmart stores or Walmart.com.



Parts

- A** Chair Back
- B** Chair Seat
- C** Side Stretcher
- D** Front Stretcher
- E** Left Leg
- F** Right Leg

- 1** Ø1/4"x80mm Bolt
- 2** Lock Washer
- 3** Flat Washer
- 4** Ø1/4"x40mm Bolt
- 5** Ø1/4"x60mm Bolt
- 6** Ø4x45mm Screw
- 7** Allen Wrench

Hardware

